

DIGITAL WALLPAPER INSTALLATION INSTRUCTIONS

Wall Prep

The surface must be clean, dry, and free of loose paint and wallpaper, remove residual wallcovering adhesive for best results – use DIF liquid or gel for fast and safe removal. Stains should be sealed with a Zinsser Shieldz primer sealer.

Prime Walls:

- New and existing (drywall, plaster): Prime the walls using Scotch Paint Draw-Tite or Zinsser Gardz. Follow manufacturer instructions for application and dry times. Existing walls present varied conditions, but they should essentially be brought to a condition whereby glossy surfaces are sanded, irregularities repaired, and the surfaces primed.
- High gloss enamel: Scuff sand first; wipe down and prime.
- Plaster and masonry: Surfaces should not exceed 5.5% moisture as measured by a moisture meter. Do not install a wallcovering unless a temperature above 55° is maintained in both areas of installation and storage for three days before and three days after installation. If there are any questions concerning the surface to be covered, a test installation is applied three days before the installation is recommended.

Installation

- The wallpaper must be installed only under permanent lighting conditions. The temperature in the area to receive vinyl wallcovering shall be maintained between 60° and 80° F, with relative humidity at 50% or less, for at least six days prior to and after installation.
- The wallpaper must be installed by experienced contractors only.
- Carefully examine the material before installation to ensure the correct design, color, quantity, panel numbers, etc.
- Surfaces should be protected from damage until the work is accepted by the architect/designer, their representative, or another appropriate person.

Important!

Selvage must be trimmed before installation to ensure proper alignment. Before overlap is double-cut, the pattern must be aligned from top to bottom. Note: the pattern may seem to be aligned at the top due to design characteristics but not on the bottom due to the panel not being completely aligned. If this is observed, move the panel over until the pattern is aligned. There is typically a ½" – 2" overlap/bleed depending on the width of the pattern and material. Flavor Paper digital wallpaper is unique to each project. If pattern alignment, drop sequence, panel placement, etc. are not completely clear, please request more detailed instructions prior to installation.

Before cutting, examine the goods to ensure the pattern color is satisfactory and as ordered. Install all wallpaper under adequate lighting and heated conditions when the space is occupied.



TASTY HANDSCREENED AND DIGITAL WALLCOVERINGS

EST. 1970
[SORT OF...]

FLAVOR PAPER

216 PACIFIC ST. BROOKLYN NY 11201

718.422.0230
SALES@FLAVORPAPER.COM

Do not use tape on the imaged surface. Align the top and adjoining edges. Smooth panels into place using a smoothing brush, starting at the center of the panel and working toward the edges. Push out any air pockets using a smoother brush. Folding or creasing can damage the wallpaper.

Paste Info for all Materials Other Than Pre-Pasted

Use clear adhesives such as Roman Professional Ultra Premium Heavy Duty Clear Strippable (PRO-880) or Golden Harvest GH-34 Clear Strippable. Clay adhesives such as Roman PRO-732 and PRO-774 have also shown to be effective. Use Roman Professional Heavy Duty Clear Pro-838 for more permanent wallcoverings. Apply a coat of the desired adhesive using a low nap roller, paste the non-woven backing or the wall, and apply wallpaper. If the material has a scrim or Osnaburg backing, you need to paste the backing and book for 5-10 minutes before hanging.

Pre-Pasted Wallpaper

Apply a thin coat of water using a low-nap roller or submerge in a tray or tub of water for a few seconds. Make sure the paste looks even and activated over the entire surface but not runny or drippy. Book for 5-10 minutes before hanging. Booking with a consistent time will help ensure even expansion and a good match.

Cleaning

Stains and paste on the surface should be removed quickly to eliminate any possible reaction between the staining agent and the wallpaper. Ordinary dirt and smudges can be removed with a mild soap and warm water mix. Blot dry with a soft, lint-free towel. Try an inconspicuous spot first before attempting the entire wall. Steel wool or powdered abrasive cleaners are not recommended for cleaning. Do not use active solvent-type cleaning preparations, such as nail polish removers, tar, and bug removers, or liquid cleaners with alcohol content. *If the wallcovering is not laminated, be extremely careful not to stain/damage it!!!!

DO NOT HANG MORE THAN THREE STRIPS/DROPS WITHOUT CAREFUL INSPECTION BEFORE PROCEEDING. IF THERE ARE ANY ISSUES, PLEASE CALL US IMMEDIATELY. WE WILL NOT BE HELD RESPONSIBLE FOR WALLPAPER OVER THREE DROPS.

Thank You for Adding Flavor to the World! !



TASTY HANDSCREENED AND DIGITAL WALLCOVERINGS

EST. 1970
[SORT OF...]

F L A V O R P A P E R

216 PACIFIC ST. BROOKLYN NY 11201

718.422.0230
SALES@FLAVORPAPER.COM