

# QUICKY STICKY INSTALLATION INSTRUCTIONS

Peel It. Stick It. Love It! Move It?

## Wall Prep

When placing the wallpaper on a standard painted wall, make sure the surface has been primed prior to painting (otherwise the paint or adhesive may come off). Regarding newly painted surfaces, make sure you allow 30 days for out gassing to prevent bubbling. Ultra-flat or matte paints can have adhesion issues, so test first. If you place the paper on a pebbly, textured surface that has eggshell paint or a very porous surface (i.e. brick, cement walls, stucco, etc.), you may receive poor results, although it has worked in many cases. So, you may want to test first for a couple of days.

To make sure the surface is ready to roll, give it a light rubdown with a warm, damp cloth or sponge and allow it to completely dry. Double check that previous cleaning solutions are completely gone as well. And, if your walls have any irregularities, touch them up with either spackle or drywall compound then prime and seal. You can remove and replace the wallpaper several times if keeping the adhesive surface meticulously clean; however, once the adhesive collects too much dust, dirt or fibers it will become less effective and the paper may not stick as well to your surface.

## Stick It Up

Depending on the size of the wallpaper, it may be helpful to have two people install it. Try not to let the adhesive come together or let the paper fold up against itself. Don't panic, it's okay if it does; you can separate it by carefully pulling it apart. Start at the top of your design and pull down approximately 4-to-6 inches of the liner and crease the back of the liner. Simply apply the 4-to-6 inches of exposed adhesive area to your chosen location. It can be repositioned several times. Once you're square (using a level) then continue to slowly pull the liner downward in 4-to-6-inch increments, smoothing the wallpaper with clean hands as you go. Depending on the size, it may be helpful if one person pulls down the liner, while the other smooths the design on the surface. You can use a felt tip squeegee to help smooth it out. If there are any bubbles or wrinkles, you can lightly press or smooth them out, or just peel back that area and re-apply. Please Note: Pressing too hard will not damage the wallpaper; however, it may cause your hands to gather ink (due to the natural oils on your hands) and could transfer from your hands onto another surface. P.S. Hang onto the liner if you think you might want to move and reuse the paper.

## Bubbles

If a bubble re-appears over the next day or two, pressing and lightly rubbing the wallpaper can remove it. This can happen occasionally if oil, dirt or dust is on your surface. Use a sewing pin to pop the bubble, and then smooth it out with your fingers in a circular motion. In the very rare instance that bubbles keep re-appearing, you may want to move your wallpaper to another area as there is something preventing the adhesive to stick. Most causes of bubbles are because the wall was painted within the last 30 days or cleaning chemicals were used prior.

## Remove It. Move It.

Wanna shake things up? To remove the paper, simply pull one of the top corners from the wall and draw the material down against itself on a 180° angle at a slow and consistent speed until the panels is completely removed. Proper prior surface prep should ensure complete removability without any damage to the wall surface. If you're planning on moving and rehanging the paper, carefully place it back on the liner and repeat previous steps. Quicky Sticky can be reused depending on how long the wallpaper has been adhered, temperature exposures, and original wall condition it was applied to.

Enjoy + Thanks for Adding Flavor to the World!!

